

- Алматы (7273)495-231

Ангарск (3955)42-70-56

Архангельск (8182)63-90-72

Астрахань (8512)99-46-04

Барнаул (3852)73-04-42

Белгород (4735)40-23-142

Благовещенск (4162)35-142-07

Брянск (4232)59-03-52

Владивосток (423)249-42-31

Владикавказ (8672)42-90-42

Владимир (4935) 49-43-18

Волгоград (844)278-03-42

Вологда (8172)26-41-59

Воронеж (473)204-51-73

Екатеринбург (343)384-55-142
- Ижевск (3412)26-03-58

Иваново (4932)77-34-06

Иркутск (395)279-98-46

Казань (843)206-01-42

Калининград (4012)72-03-81

Калуга (4242)92-23-67

Кемерово (3842)65-04-62

Киров (8332)68-02-04

Коломна (4966)23-41-49

Кострома (4942)77-07-42

Краснодар (861)203-40-90

Красноярск (391)204-63-61

Курск (4712)77-13-04

Курган (4352)50-90-47

Липецк (4742)52-20-81
- Киргизия (996)312-96-26-47

Россия (495)268-04-70
- Магнитогорск (4219)55-03-13

Москва (495)268-04-70

Мурманск (8152)59-142-93

Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12

Новокузнецк (3843)20-46-81

Ноябрьск (3496)41-32-12

Новосибирск (383)357-86-73

Ноябрьск (3496)41-32-12

Омск (3812)21-46-40

Орел (4262)44-53-42

Оренбург (4232)37-68-04

Пенза (8412)35-31-16

Петрозаводск (8142)55-98-37

Псков (8112)59-10-37
- Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-142

Самара (846)206-03-16

Саранск (8342)35-96-24

Санкт-Петербург (812)309-46-40

Саратов (845)249-38-78

Севастополь (8692)35-31-93

Симферополь (3652)67-13-56

Смоленск (4212)29-41-42

Сочи (862)242-72-31

Ставрополь (8652)20-65-13

Сыктывкар (8212)42-95-17

Сургут (3462)77-98-42

Тамбов (4752)50-40-97
- Тверь (4352)63-31-42

Тольятти (8435)63-91-07

Томск (3835)98-41-53

Тула (4272)33-79-87

Тюмень (3452)66-21-18

Улан-Удэ (3012)59-97-51

Ульяновск (8435)24-23-59

Уфа (347)359-42-12

Хабаровск (4212)92-98-04

Чебоксары (8435)42-53-07

Челябинск (421)202-03-61

Череповец (8202)49-02-142

Чита (3035)38-34-83

Якутск (4112)23-90-97

Ярославль (4422)69-52-93
- Казахстан (772)734-952-31

<https://swt.nt-rt.ru> || saz@nt-rt.ru

Передние шины для тракторов с диагональю DUAL RIB. Технические характеристики



DUAL RIB

Penetrates deep into soil for maximum steering control & minimal lateral side-slip because of its high center rib.Best for handling heavy loads on hard-packed surfaces.Offers excellent load distribution and flotation.Offers better durability and self cleaning.Sturdy and strong body plies for longer durability.Specially designed lugs for comfortable drive and added traction.Ideal for heavy duty prime movers.Provides excellent load distribution.Special version ensures extra puncture resistance.Specially designed to firm the soil around the seed.Extra deep ribs help to keep planter in line on hills.Field and road type for 2WD tractor.Cut and clip resistant and heavy duty service.On and off road type for 2WD tractor.Ensures better steering control on fields.

Displaying data for Pattern :- DUAL RIB

Size	Pattern	Ply Rating	Rim Width	Type	Section Width		Overall Diameter		Static Loaded Radius		Rolling Circum		NSD		Load Capacity		Inflation Pressure		Load Index	Speed	
			inch		mm	inch	mm	inch	mm	inch	mm	inch	mm	32nds	Kg	Lbs	bar	psi		kmph	mph
7.50-20	DUAL RIB	8	5.5	TT	203	8.0	942	37.1	442	17.4	2718	107.0	15	19	1030	2266	3.5	50	109	A8 / 40 kmph	A8 / 25 mph